

FOR THOSE WHO LACK THE HEAD, NECK OR JAW MOVEMENT NECESSARY TO PUSH BUTTONS WITH THEIR CHIN, OR FOR USER'S PREFERENCE, A "SIP & PUFF" CONTROL SYSTEM IS AVAILABLE.



FOR **SIP & PUFF CONTROLLED FISHING**, THE USER SIMPLY STRAPS ON THE CHEST PLATE WHICH SUPPORTS A FULLY ADJUSTABLE ARM AND CONTROL BOX CONTAINING 3 PRESSURE SWITCHES.

EACH SWITCH IS CONNECTED TO A STIFF, YET FLEXIBLE LOC-LINE MODULAR HOSE THAT WILL STAY IN PLACE ONCE THE END NOZZLE IS POSITIONED FOR USE.

LIKE THE PUSH-BUTTONS, THE SIP & PUFF SWITCHES CAN BE USED IN A SEQUENCE TO EASILY CREATE A "PUMPING ACTION" WITH THE FISHING ROD ALLOWING THE USER TO FIGHT, PLAY-OUT AND LAND LARGE FISH. WITH ALL THREE NOZZELS POSITIONED IN THEIR MOUTH, THE FISHERMAN SIMPLY "PUFFS" TO PULL BACK ON THE ROD, THEN "SIPS" TO DROP THE ROD TIP FORWARD AND WIND IN LINE.



ADAPTIVE CREATIONS
P.O. BOX 131
WALTERSBURG, PA 15488

PH: 724-438-1336

kendvorchak@kenspowercaster.com

ADAPTIVE CREATIONS

presents

**KEN'S
POWER
CASTER**



**FULLY AUTOMATED
ADAPTIVE EQUIPMENT
for
FISHING**

THE KEN'S POWER CASTER IS THE WORLD'S FIRST AND ONLY **FULLY AUTOMATED**, PUSH-BUTTON CONTROLLED FISHING MACHINE. NOW, WITH THIS "GOLD MEDAL" AWARD WINNING INVENTION, FISHING IS AS EASY AS 1, 2, 3...



STEP 1 - PRESS A BUTTON UNTIL THE CASTING ARM AUTOMATICALLY STOPS IN THE "BACK POSITION"

STEP 2 - PRESS A BUTTON UNTIL THE CASTING ARM AUTOMATICALLY CASTS OUT THE LINE AND STOPS IN THE "FISHING POSITION"



STEP 3 - PRESS A BUTTON TO RETRIEVE LINE, WORK A LURE, HOOK AND LAND FISH



FOR **TOTALLY HANDS-FREE FISHING**, THE USER SIMPLY STRAPS ON THE CHEST PLATE WHICH SUPPORTS A FULLY ADJUSTABLE ARM AND CONTROL BOX CONTAINING THE THREE PUSH BUTTON SWITCHES THAT CAN EASILY BE OPERATED BY THE USER'S CHIN

FOR **EXTREMITY CONTROL**, THE CONTROL BOX CAN EASILY BE MOVED AND POSITIONED IN THE MOST ACCESSIBLE LOCATION FOR EACH AND EVERY USER



KEY FEATURES:

- THE MOUNTING BRACKET CAN BE SECURED TO ALMOST ANY ACCESSIBLE SURFACE (i.e. a wheelchair, dock rail, deck, boat rail, etc.)
- THE CASTER TURNS ON THE MOUNTING BRACKET TO ALLOW CASTING IN ANY DIRECTION
- THE CASTER SWIVELS AND FOLLOWS A HOOKED FISH SWIMMING IN THE WATER TO MAINTAIN THE PROPER FIGHTING POSITION
- THE THREE PUSH BUTTONS, WHICH CONTROL ALL OF THE FUNCTIONS OF THE CASTER, CAN BE ACTIVATED IN A SEQUENCE TO CREATE A "PUMPING ACTION" WITH THE FISHING ROD ALLOWING THE USER TO FIGHT, PLAY-OUT AND LAND LARGE FISH
- CONSISTANTLY CASTS A LARGE SIZE WOODEN EGG BOBBER 100 FEET. ALTHOUGH LIGHTER LURES AND BAITS WON'T CAST QUITE AS FAR, IT WILL CAST HEAVIER BAITS AND LURES OVER 100 FEET.
- RUNS OFF OF ANY 12-VOLT POWER SOURCE. YOUR WHEELCHAIR BATTERY CAN BE USED TO CREATE A COMPACT SYSTEM GIVING YOU THE FREEDOM TO CHANGE LOCATIONS WITHOUT INTERRUPTION
- COMES COMPLETELY ASSEMBLED AND INCLUDES A SHAKESPEARE PRIUS 7' SPINNING ROD AND A ZEBCO 33T ELECTRIC RETRIEVE REEL
- GIVES EVERYONE THE ABILITY TO FISH WITH INDEPENDENCE!